ADVENTURE FURTHER®

OVERHEAD MOUNTING BRACKET
2021-2024 FORD BRONCO

INSTALLATION INSTRUCTIONS

WARNING: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.









Overhead Installation

1. Using a trim/panel removal tool, remove the plastic covers on the vehicle (the covers are labeled on the windshield with “accessory ready”).
2. Remove the plastic holder underneath using a 10 mm socket to expose the factory mounting studs.
3. Install the overhead bracket into position over the factory mounting studs and reuse the factory nuts. Torque to 97 in-lbs.
4. Once the brackets are securely installed (see images below) the brackets are ready for the Pro6/Titan light bar to be installed. Follow the Pro6 wiring installation to complete the Pro6 Light Bar installation.

Pro6/Titan light bars must be in the curved format to fit correctly



PRODUCT REGISTRATION

Thank you for becoming part of the KC family and purchasing one of our premium KC products! With over 50 years of history in the auxiliary lighting market, you have become a part of our ever growing family, and we encourage you to register your product online at HTTP://REGISTER.KCHILITES.COM to ensure you get all the benefits of owning a KC HILITES product.

©Copyright 2025 KC HiLiTES, Inc.