ADVENTURE FURTHER®

1” WEBBING STRAP HOOK
PL1
92512 | 59-00286IM

INSTALLATION INSTRUCTIONS

IMPORTANT: Please read all instructions before beginning installation. These guidelines are provided in good faith to help prevent any issues arising from errors during installation. The manufacturer of this product shall not be held responsible for any user actions taken or not taken during installation. There are many details of the installation that are assumed to be general mechanical knowledge to experienced installers; which are not detailed in these instructions. These installation guidelines are intended to serve as professional recommendations and are not as a step-by-step, fail-safe installation checklist. Selection of an experienced installer is the sole responsibility of the project owner.





TOOLS NEEDED: METRIC ALLEN KEY SET

1



THIS PRODUCT IS INTENDED TO ACCEPT ANY 1” WEBBING LOOP; COMMONLY FOUND ON AWNING SETUPS.

2



DETERMINE THE BEST POSITIONING FOR YOUR STRAP HOOK. SLIDE THE M8 NUTS INTO THE EXTRUSION CHANNEL. PLACE THE BRACKET IN THE DESIRED POSITION AND FASTEN THE M8 BUTTON HEAD SCREWS.

©Copyright 2025 KC HiLiTES, Inc.