

GLADIATOR REAR INNER FENDERS (INFEND-04RB)

1. Unpack your new rear inner fenders and inspect all items. You should have two inner pieces (left and right) and two outer pieces (left and right) and a small box of hardware.
2. Begin by joining each inner with the corresponding outer piece with supplied hardware. **NOTE:** The lip on the smaller inner piece will sit behind the outer piece as shown in the image below.



3. Once joined, place inner fender in inner wheel well. You will have to remove most fenders to install.



4. Line up the holes on the front and back of the inner fender first. Attach loosely.



5. The rounded edge near the rear sits behind the lip of the wheel well as shown.



6. Attach last three bolts on the bottom of the inner fender with supplied hardware. Tighten all hardware until inner fender secure.

