INSTRUCTIONS FOR JEEP TJ/LJ

BRACKET SET #7340

Thanks for choosing a KC product. We take pride in building the highest quality, best engineered systems possible. Your satisfaction with our product is important, so if you have any questions, please call our customer service line at 888-689-5955. For warranty information, visit our website at www.kchilties.com/warranty.

**NOTE - This bracket set is designed for the 50” Gravity® Titan and Pro6 light bars.



#7340

PARTS INCLUDED

- 2 - Above windshield light mounting brackets
- 6 - 5/16 x 11/4 black zinc bolts
- 6 - 5/16 black zinc washer
- 2 - Protective gaskets

INSTALLING THE BRACKETS

1. Remove the three Torx head bolts from each of the upper windshield frame hinge brackets.
2. Align the rubber gasket over the holes on the vehicle. It can be held in place with a couple of pieces of scotch tape or the like.
3. Lay the bracket over the gasket and align the holes. Start and hand tighten each of the three bolts with washers. (Do not fully tighten at this time.)
4. Install your light bar onto the brackets using the hardware included with the bar and tighten securely.
5. After the bar is in place, fully tighten the brackets on the vehicle.
6. Wire the bar according to the instructions included with the LED bar.

YOU’RE DONE!!!

©Copyright 2026 KC HiLiTES, Inc.